

Customization Options

SeaDek is easy to install, customizable, and available in a variety of sizes, thicknesses and colors. SeaDek can be tailored to fit a wide variety of applications on just about any type of boat including: sport & commercial fishing boats, flats boats, sailboats, ski boats, commercial marine craft, house boats, personal watercraft, towboats and more.


COLOR OPTIONS



TEXTURE OPTIONS




Brushed




Embossed

PATTERNS


Popular Patterns



Outer Route




Pinline




2.5" Faux Teak


Custom Patterns




Tarpon Scales




Diamond




6" Plank



Hexagon



Bamboo



Gator Belly


Representations of the pattern, final routing may vary.

THICKNESS OPTIONS


actual thickness




5 mm
Single Color



6 mm
Two Colors



8 mm
Two Colors



10 mm
Two Colors



13 mm
Two Colors



20 mm
Two Colors




23 mm
Two Colors

Stock SeaDek Colors

MARINE PRODUCTS

What is a “stock color?” Stock colors are sheets of SeaDek that we have readily available to cut. Having stock colors on hand means that we don’t have to place an order for your foam which, in-turn, means that you’ll be enjoying your freshly #seadeked boat in no time!



B = brushed texture only | E = embossed texture only | A = all textures

Wondering how these colors look on a boat?

Simply open up **Instagram** on your phone or web browser and search for the tags listed below the swatch. Searching these tags will allow you to see the colors applied in various areas and lighting conditions. we love to see people enjoying our products! Be sure to include #castawaycustoms in your posts!

Examples

LOGOS

Custom logos can easily be added to your boat. Prices will vary depending on size and machine time.



OUTER ROUTE

Provides the most foam surface area while letting the secondary color show around the outsides of the cut.



PINLINE

Adds that extra finishing touch to your boat.



2.5" FAUX TEAK

Furnishes your boat with the classic look of a teak deck or swim platform without the costly maintenance of real teak.



NOTES

The Process


SCANNING

We will come to you, or you can come to us and we will use our state-of-the-art machines to precisely measure every surface of your boat where you want SeaDek installed.



DRAWING

One of our experienced CAD designers takes all the scans of your boat and will draw out every piece.



CUTTING

Our CNC machines shape the foam with extreme accuracy and are inspected for quality by our machinist before heading out for installation.



INSTALLING

We will come to you, or you can come to us and one of our installers will ensure that every break lines up just right by inspecting it from multiple angles before sticking in place.



PAYMENT

Castaway Customs requires a \$100 non refundable deposit prior to digitizing. The deposit will be applied towards the final invoice. Upon completion of scan, a formal estimate based off exact square footage including the customers options and specs will be provided. Once approved, a 50% deposit will be taken.

A proof based off of customers options and specs will be provided. One major revision (changing pattern or breaks) and two minor revisions (changing logo placement) will be provided free of charge. Additional revision charges may vary based on time tracked.

Once the proof is finalized the job will move into production and the install will be scheduled.

Remainder of balance is due upon completed installation.

All sales are final after 30 days.

Accepted types of payment: Cash, Cashiers Check, Check, Visa, MasterCard, Amex, Discover

Warranty

HYPERFORM, INC. LIMITED WARRANTY FOR SEADEK PRODUCTS

Thank you for your purchase of a Hyperform, Inc. product. This Limited Warranty (the "Warranty") is made by HYPERFORM INC. ("Hyperform"), a Florida corporation, in connection with the Buyer's purchase of a Hyperform product, as more fully defined in that certain purchase order of even date herewith ("the Covered Product"). This Warranty constitutes the entire agreement between Hyperform and the Buyer as to any warranty provided by Hyperform to the Buyer on the Covered Product

WHAT THIS LIMITED WARRANTY COVERS. Hyperform warrants to the Buyer ("Buyer", for purposes of this Warranty, means only first purchaser of the Covered Product and does not extend to subsequent purchasers) that the Covered Products are free from defects in workmanship and materials at the time of manufacture and for a period of thirty-six (36) months from the date the Covered Products are shipped from Hyperform for delivery to the Buyer. The limited warranty provided hereunder is subject to the strict precondition provided that the Covered Products are used and maintained in accordance with all Hyperform specifications for preparation, installation, storage, as set forth in the two documents, Storing SeaDek Instructions (TAB 4-21) and Applying SeaDek Instructions (TAB 4-20), relevant to the Covered Product, which may be found posted at seadek.com. Improper installation and/or repair voids this Warranty in its entirety, without exception.

I. ACKNOWLEDGMENTS OF BUYER.

By purchasing a Hyperform product, Buyer accepts this Warranty and acknowledges the following:

- A. That Buyer has read and understands and agrees to the terms and limitations of this Warranty.
- B. That Buyer has been provided with sufficient opportunity to consult with independent legal counsel regarding this Warranty and the limitations hereof, and that Buyer has not relied upon any statements or representations of Hyperform for Buyer's understanding or interpretation of any provision hereof.

II. WHAT THIS LIMITED WARRANTY DOES NOT COVER.

This limited warranty does not cover the installation of the Product onto any surface, nor does it cover adhesion of the Product to the boat or to any other surface to which the Covered Products are applied. This warranty applies only to material and workmanship of the Covered Product itself. Some fading and/or discoloration of the Covered Products may occur with time and use in the marine environment; such fading and/or discoloration is not covered by this limited warranty. This limited warranty covers only excessive fading or polymer degradation resulting from defective materials. This warranty specifically EXCLUDES deformation, discoloration or other damage to the Covered Product, and EXCLUDES all other damage or loss, resulting from the Covered Product's being subjected to temperatures in excess of 165°F ("Max Temp"). See Light Amplification (TAB 4-26). Max Temp may occur for example in certain specific installations which result in light amplification at the Covered Product surface due to reflection of sunlight from reflective surfaces or refraction of sunlight through light-transmissive surfaces such as windshields or optically clear structures. Care should be taken to avoid installing the Covered Product in such areas. It is exclusively the Buyer's responsibility to provide assurance that any particular installation will not exceed the Max Temp. Hyperform, Inc. shall not be responsible for any damage or loss resulting from any application or use of the Covered Product which exceeds the Max Temp. Installations resulting in the Covered Product's experiencing temperatures in excess of the Max Temp shall void this Warranty in its entirety.

III. WHAT HYPERFORM WILL DO.

Covered Products determined by Hyperform to have material and/or workmanship defects will be covered as follows. Products deemed by Hyperform to be defective within thirty-six (36) months of shipment to Buyer will be replaced or a refund for the defective product will be provided. At Hyperform's sole option, they may choose to cover the shipping charges of the replacement pad for shipping within the U.S. The Buyer will be responsible for all shipping charges for international shipping.

PROCEDURE. The Buyer shall first submit a completed End User/Dealer/Distributor/Cert Fabricator Warranty Replacement Request and supporting photographs depicting the defective condition and/or return the product. The instructions for this process can be found within the Return Material Authorization (RMA) document (Form 4-13). If deemed defective by Hyperform an RMA (Returned Merchandise Authorization) will be issued along with a credit or a replacement pad for the defective Product in accordance with the terms stated herein.

IV. LIMITATIONS ON HYPERFORM LIABILITY AND MISCELLANEOUS PROVISIONS.

- A. Hyperform's total liability under this Warranty shall not exceed the replacement value of the Covered Product.
- B. In no event will Hyperform be liable under any theory of liability or be obligated for consequential or indirect damages of any type or nature.
- C. This Warranty shall not be assigned or transferred by the Buyer without the prior written approval of Hyperform.
- D. This Warranty shall be governed by and construed according to the laws of the state of Florida, U.S.A. The Parties agree to personal jurisdiction in the state of Florida, and venue in Brevard County, Florida, or in the Federal Court for the Middle District of Florida, Orlando Division.

V. WARRANTY DISCLAIMERS.

- A. THIS WARRANTY SUPERSEDES AND REPLACES ANY PREVIOUS WARRANTY MADE OR OFFERED TO THE BUYER BY HYPERFORM AND SEADEK, INCLUDING BUT NOT LIMITED TO ANY WARRANTY SET FORTH IN ANY OTHER AGREEMENT BETWEEN THE PARTIES HERETO.
- B. HYPERFORM SPECIFICALLY DISCLAIMS ALL WARRANTIES OF ANY KIND, EXPRESS OR IMPLIED, NOT SPECIFICALLY SET FORTH IN THIS WARRANTY. OTHER THAN AS SPECIFICALLY SET FORTH IN THIS WARRANTY; (1) THERE ARE NO WARRANTIES ESTABLISHED OR IMPLIED; (2) THERE ARE NO WARRANTIES WHICH EXTEND BEYOND THE DESCRIPTION ON THE FACE HEREOF; (3) NO EXPRESS WARRANTY IS GIVEN; AND (4) NO AFFIRMATION OF FACT OR PROMISE MADE BY HYPERFORM, BY WORD OR ACTION, SHALL CONSTITUTE A WARRANTY.
- C. ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND/OR FITNESS OR SUITABILITY FOR A PARTICULAR PURPOSE ARE EXPRESSLY EXCLUDED FROM THIS WARRANTY.
- D. EXCEPT FOR THE PROVISIONS SET FORTH IN THIS WARRANTY, NO AGENT, EMPLOYEE, SUBCONTRACTOR, OR REPRESENTATIVE OF HYPERFORM HAS ANY AUTHORITY TO BIND HYPERFORM TO ANY OTHER AFFIRMATION, REPRESENTATION, OR WARRANTY CONCERNING THE PRODUCT SOLD TO THE BUYER. UNLESS AN AFFIRMATION, REPRESENTATION OR WARRANTY IS SPECIFICALLY INCLUDED IN THIS WARRANTY, IT SHALL NOT BE ENFORCEABLE BY THE BUYER.
- E. HYPERFORM MAY, FROM TIME TO TIME, IN THEIR SOLE DISCRETION OFFER TO REPAIR OR REPLACE COVERED PRODUCT IN CERTAIN SPECIFIC SITUATIONS. SUCH OFFERS BY HYPERFORM, INC, IF MADE, ARE NOT TO BE CONSTRUED AS A WAIVER OF ANY EXCLUSION OR OTHER LIMITATION TO THIS WARRANTY STATED HEREIN, NOR ARE THEY TO BE TO BE CONSTRUED AS A COURSE OF DEALING THAT IN ANY WAY MODIFIES THE TERMS OF THIS WARRANTY.

Installation / Care

INSTALLATION

TOOLS:

1. Sharp razor knife
2. Isopropyl Alcohol or Acetone
3. 1-Inch Masking Tape

VIDEOS OF INSTALLATION:

1. Watch a video demonstration of installation on the SeaDek website at: www.seadek.com under the DIY section.

STORAGE:

1. SeaDek should be stored in a cool, dry, indoor location until installed on boat.

INSTALLATION LIMITATIONS:

1. Do NOT install SeaDek in temperatures below 60 degrees Fahrenheit.
2. Do NOT attempt to remove and adjust placement once pad is down.

PREPARATION:

1. Use isopropyl alcohol or acetone on the surface area. Thoroughly clean the surface area where SeaDek will be applied. Please follow your state regulations for proper chemical handling.
2. Make sure all grease, adhesive, mold-release, wax and other substances are removed before installing the product. The area must be completely dry before applying pads.

INSTALLATION:

1. Before you peel back the adhesive backing, place the pads on the surface area to verify the fit and spacing in order to determine the exact location of the pad(s).
2. Turn pad over so that the adhesive backing is face up. With a sharp razor knife carefully cut the paper adhesive backing from the center of the pad towards the edges (center to top edge, center to bottom edge) to ensure it does not rip. Be sure to completely cut through the adhesive backing but DO NOT cut into the pad.
3. Now starting from the center cut you just made, peel back 2" of the paper backing and fold to crease it. Repeat on the other side. Fold both pieces of the paper backing back in place to cover the adhesive.
4. Turn the pad back over and reposition it exactly where you want it installed.
5. Firmly secure one side of the pad to the surface area using 1-inch masking tape. Taping prevents the pad from moving.
6. Lift up the side that is not taped down and peel the paper backing to the crease. Gently lay the pad back in place.
7. Firmly press down on the pad where the exposed adhesive is. Apply pressure from the center of the pad outward (center to top, center to bottom) to ensure no air is trapped beneath the pad.
8. Continue to lift the pad and peel back the paper backing to expose an additional 2" - 3" and repeat step 7.

DO NOT PULL OR STRETCH THE PAD(S)

9. Once the first side is complete, remove the masking tape and repeat steps 7 and 8 for the other half of the pad. Apply pressure to the pad to ensure there's a firm bond between the pad and the surface area.
10. Firmly press down on all edges to ensure no water will permeate the pads.

CARE/CLEANING

1. To clean dirt, footprints, etc. from your SeaDek, use an all purpose cleaner, such as Formula 409®, and warm water along with a medium bristled deck brush. Put the cleaner in warm water. Take a medium bristled brush and dunk into the soapy water. Work around on SeaDek until dirt, etc. comes up. Rinse with water. Repeat if necessary.
2. To remove suntan lotion, use the all purpose cleaner alone with a medium bristled deck brush. Put small amount of the all purpose cleaner on oil. Dip medium bristled boat brush in warm water and work around until oil is out. Rinse with water. Repeat if needed.
3. To remove fish blood, use 1 cup bleach to 1 gallon of warm water and soft bristled boat brush. Mix bleach and water take soft bristled brush and dunk in water. In a circular motion clean SeaDek until fish blood is up. Rinse with water. Repeat if necessary. If not effective, see step 4.
4. To remove rust stains, use a cap full of MaryKate On & Off Hull & Bottom Cleaner for fiberglass. Apply on the rust stain and allow to soak for 3-5 minutes. If necessary, use latex/nitrile gloves to massage the cleaner into the brushed or embossed texture of the SeaDek pad. Rinse with water. Repeat if necessary, the rust stain will eventually be removed. With MaryKate Hull Cleaner, please be careful to avoid getting this solvent on the sides of the SeaDek pad, it could damage the lamination or PSA.

Please be careful with all cleaning products. Wear vinyl or nitrile gloves and eye protection.

SOLVENTS TO AVOID

DO NOT USE:

–Mineral Spirits

–Mary Kate Hull Cleaner
(not as a general cleaner, okay for Step 4 application only)

–Acetone
(if it must be used, avoid the adhesives as best as possible)

–Bleach
(if used, dilute 1:1 with water)

For best cleaning results, tend to all stains, spills and leaks as soon as possible

Light Amplification

LIGHT AMPLIFICATION

Light amplification occurs when the sun reflects off of certain surfaces, and is directed into one spot on the SeaDek, which damages it. When this happens in certain applications, under certain conditions the SeaDek can be exposed to temperatures above the operational temperature of 165°F (73°C).

Lighter colors reduce the light amplification problem. However, it will not be covered under our standard warranty if light amplification occurs. Other material problems will still be covered.


After installation, the preferred method of storage is that the boat (or any other surface of application) be covered. SeaDek pads are very durable, but they will last longer and the colors will fade more slowly if they are not exposed to the elements when not in use. Examples include keeping the boat; in a garage, covered with a canvas boat cover, in a covered boat slip, etc.

Situations to Avoid:

Inflatable pool toys or water bottles stored long-term on SeaDek, or placing SeaDek near reflective surfaces or beneath glass as detailed in Section II in the SeaDek warranty.

These objects can refract/reflect light, thereby concentrating the beams to a level which can be destructive to the SeaDek pad.

LIGHT REFLECTION



LIGHT AMPLIFICATION BURNS

